


myjoy

Wireless Earphones

USER MANUAL



Wireless Earphones

- Listen to Music & Answer calls wirelessly.
- Compatible with any Phone.
- Ultra fast charge.



40 Mah



400 Mah

SPECIFICATIONS CHARGING TIME

Model Name: My Joy

Connection Version: 5.3

Data Interface: TYPE C

Operating Distance: >33ft/10M

Driver Unit: 10 mm

Impedance: 32 Ω

Sensitivity: 100 \pm 3dB

Frequency: 20Hz-20KHz

Charging Time: 1 hour for earbud / 2 hours for charging box

Playtime: 6 hours

Support Function: Answer / End / Reject / Play / Pause /
Previous Track/ Next Track / Volume Up

Technical Support & Warranty Information

*Please read before using this product.


SAFETY & CARE INSTRUCTIONS

- Do **NOT** expose any portion of this product to liquid, humidity, moisture, sharp objects, or extreme temperatures as this can damage it and void the warranty.
- Do **NOT** attempt to modify or disassemble the Earbuds or Charging Case in any way.
- Spot Clean **ONLY SPECIFICATIONS CHARGING TIME.**


CHARGING YOUR myjoy Earphones

- Place each earbud into its charging slot and close the cover.
- Use the charging cable provided and plug the other end into any USB charging port.
- To prevent damage, it is recommended to use the charging cable that is provided. Fully charge the charging case and earbuds for a minimum of 3 hours before first use.


1



2



SCAN/SEARCH & SELECT **myJoy**



- Once paired, My Joy will voice prompt 'CONNECTED'.

Single Earbud Mode: When is connected, you can use either Earbud of the earbuds only by putting the other one back into the charging case and closing the cover.


NOTE: Power on MyJoy and they will automatically connect to the last connected device if available within the connection range.

EARBUD TAP-TOUCH FUNCTION GUIDE

NOTE: My Joy has a sensitive tap-touch feature. There is a multi-function touch button on each earbud.

POWERING ON/OFF

- To automatically power on, take the earbuds out of the case.
- To automatically power off, place the earbuds back into the charging case.
- To manually power on, press and hold the TOP on either one of earbuds for 3-4 seconds until the LED indicator flashes BLUE.
- To manually power off, press and hold button on either one of earbuds for 5-6 seconds until the LED indicator turns off.



CONNECTION PAIRING WITH YOUR DEVICE

- Open the charging case, remove the earbuds and they will automatically power on and pair to each other, voice will prompt 'CONNECTED'. The right earbud will automatically connect to the left earbud.
- Pairing mode will last for 2 minutes. While in pairing mode, turn ON the connection on your device,



Tap 2 times (L/R)



Tap 3 times (R)



Tap 3 times (L)

Volume control while music playing.



Turn volume **DOWN**

Tap Once (L)

Turn volume **UP**

Tap Once (R)

NOTE: Fully the charging case and earbuds for a minimum of 3 hours before first use.



Hours of
playtime



Rechargeable



**LIFETIME
WARRANTY**

www.mymeworld.com



**UK
CA**

CE

FC

RoHS



Made in China