

# MyMe Power Banks



Thank you for purchasing this MyMe Product. Please read this manual carefully. It contains important operating instructions.

## Purpose

This unit is designed for charging standard USB devices.

## Specification

Input:	5V DC @ 1A (Unless otherwise stated)
Output:	5V DC @ 1A (Unless otherwise stated)
Operating Temperature:	10°-40°C
Capacity:	4,400mAh
Cell Type:	Li-Polymer

## Safety Precautions

1. Do not short circuit.
2. Do not try to use this power supply with appliance requiring more than 2.1A.
3. Do not attempt to open this unit.
4. Please unplug the cable when not in use
5. Do not use if unit appears to be damaged.
6. Do not use device near water or when wet.
7. Position cables carefully, so as not to cause a trip hazard
8. For longer cables, keep out of reach of children
1. Avoid any damage to the Power Bank especially from impact.
2. Store in a cool, dry place at temperatures between -40°C and 45°C and in relative humidity below 75%.
3. Avoid contact between the device and corrosive substances and fire.
4. Do not short circuit.
5. Ensure correct voltage is used as continuous excessive voltage could damage your equipment.
6. Do not try to use this power supply with appliances requiring more than 1A.
7. Do not attempt to open this unit.
8. Do not use if unit appears to be damaged.
9. Please disconnect device when not in use.
10. Do not use device near water or when wet.
11. Please ensure the Power Bank is charged periodically (at least once every six months) to maintain its charging capacity.

## Instructions for Use

1. Before using, check your device's input voltage and this Power Bank's output voltage to ensure compatibility. Make sure the total load does not exceed the rated output current of this charger.
2. Before using the Power Bank, connect it to an appropriate USB power source using the micro USB cable included to charge it (ensure the smaller micro USB end of the cable is connected to the Power Bank and the larger USB A end of the cable is connected to the USB Power Source).
3. The LED light should start blinking to indicate that the Power Bank is being charged.
4. To use the Power Bank to charge your device, connect the larger USB A end of the cable to the Power Bank and the smaller micro USB end of the cable to the device you want to charge. To connect to devices that don't use micro USB, please use a compatible adapter or an alternative USB cable.
5. Once your device is connected, the LED lights on the Power Bank should begin to blink to indicate that your device is charging. Once charging is complete, your Power Bank should go into sleep mode and stop charging. If you disconnect the Power Bank and reconnect it to your device, it may take up to 15 seconds for the Power Bank to start charging your device again.
6. If the Power Bank does not begin charging your device, please check the connection and that the Power Bank has been charged.
7. When you have finished charging your device, please remove the cable. The Power Bank will stop charging after it is disconnected.
8. When the Power Bank is out of power, please re-charge it by connect it to an appropriate USB power source using the micro USB cable.

## After-Sales support

If you discover that this product contains a manufacturing defect which affects the operation of this device, you may return it to any site in the UK that sells MyMe accessories and exchange it for a new MyMe item of the same value, subject to availability. This does not affect your statutory rights. If you experience any problems obtaining a replacement item or require any other assistance, please contact via our email: [support@fifouk.com](mailto:support@fifouk.com)

## Correct Disposal of this product



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.

---